Using the PIC18F4620 or PIC18F4520

Historically, MIOS was developed to run on a core module stuffed with a PIC18F452. Recently, the PIC18F4620 has become available. It is near code-compatible with the 452, but features a significant increase in RAM/EEPROM/Codespace. See the PIC18F4620 page for details.

The following are intructions on converting old apps, and developing new apps, to run on the PIC18F4620. Small changes to the procedure make it compatible with the PIC18F4520 also.

OS Layers

MIOS v1.9b or above is required. You will need to download the MIOS source from The uCApps.de Download Page or Directly. I recommend checking the first link for the latest version, as the '4620 is current in beta.

The Bootloader and MIOS recompile steps which follow should not be necessary for most cases of '4620 use, as these components are now available precompiled and packaged in a zip file hosted on uCApps.de Instructions follow for reference only, or for '4520 use.

Bootloader

Bootloader v1.2, which is packaged with MIOS v1.9 and up, will need to be recompiled as follows:

- Extract the MIOS source files from the zip
- Edit bootloader\main.asm
- Change

#define PIC DERIVATIVE TYPE 0

To

#define PIC_DERIVATIVE_TYPE 1



• Burn the hex file to the PIC Fix Me! wiki link

MIOS

The MIOS Operating System itself must also be compiled, as follows:

- Edit src\mios.h from the MIOS source files
- Change

#define PIC DERIVATIVE TYPE 0

To

#define PIC DERIVATIVE TYPE 1

- Compile the project Fix Me! wiki link
- also see: Compiling the MIDIbox source on Linux using GPASM (Linux, Mac) instead of MPLAB (Windows)
- Upload the hex file with MIOS Studio



Please note that the above instructions should work for PIC18F4520 also. The only difference is that the PIC DERIVATIVE TYPE should be '2', not '1'. This stands for all of the following instructions.

Application Layer

Once your PIC18F4620 has the Bootloader burned onto it, and MIOS uploaded, you are ready to upload your application. A few modifications may be required:

Migration

If you have an existing ASM-based application, which is designed for MIOS v1.8 or lower, then you will need to migrate the application to support MIOS v1.9

- Extract the 'migration' folder from MIOS source zip file
- Overwrite the files contained in the source of your application.

Take note that this may overwrite customisations you have made to your application, so please take a backup first, and a copy for comparison with the new files.

ASM

If your application is either:

- 1. a freshly migrated application (as above)
- 2. a brand new ASM-based project based on a skeleton >= v1.9
- 3. an ASM-based application which already requires MIOS v1.9 or greater (like MBSID v1.7303)

Then the following steps are required:

- Edit mios.h in the source of your application
- Change

#define PIC_DERIVATIVE_TYPE 0

Tο

#define PIC DERIVATIVE TYPE 1

• Compile the project Fix Me! wiki link

• Upload the hex file with MIOS Studio



C

If your application is C-based, then the following steps are required. Some are optional recommendations, as noted.

Note on compile errors

When compiling your C-based application, you may see an error such as this:

```
Linking project
warning: processor mismatch in "_output\mios_wrapper.o"
```

This error is caused by SDCC compiling the application for the PIC18F452. Fortunately, the code is compatible between the two chips, so this error can be ignored. Thanks to bill, for having the guts to put the app on his PIC, and confirm that this was the case ;)

Header and Library

In the case that you should need to take advantage of the additional EEPROM on the newer PICs, the following alterations to the library and header are necessary:

- Edit pic18f452.c in the source of your application
- Change

```
sfr at 0xfa9 EEADR;
sfr at 0xfab RCSTA;
```

To

```
sfr at 0xfa9 EEADR;
sfr at 0xfaa EEADRH;
sfr at 0xfab RCSTA;
```

- Edit pic18f452.h in the source of your application
- Change

```
extern __sfr __at 0xfa9 EEADR;
extern __sfr __at 0xfab RCSTA;
```

To

```
extern __sfr __at 0xfa9 EEADR;
extern __sfr __at 0xfaa EEADRH;
extern __sfr __at 0xfab RCSTA;
```

Note that the filenames stay as pic18f452.*, regardless of the PIC model we are actually using. For our purposes, SDCC considers the '4620 to be the same as a '452.

C-Wrapper

The C-Wrapper will need to be edited as follows:

- In the source of your application, edit mios wrapper\mios.h
- Change

```
#define PIC_DERIVATIVE_TYPE 0
```

Tο

```
#define PIC_DERIVATIVE_TYPE 1
```

If you want to use this function, you may want to apply a small fix to the DEC2BCD Helper:

- In the source of your application, edit mios wrapper\mios wrapper.asm
- Change

To

```
global _MIOS_HLP_Dec2BCD //The low byte is already in W

movff FSR0L, FSR2L //These guys
movff PREINC2, MIOS_PARAMETER1 //Put the high byte in

MIOS_PARAMETER1. Yay!

goto MIOS_HLP_Dec2BCD
```

Linker Script

Modifications should be made to the linker script in order to take advantage of the additional capabilities of the 4620/4520. If you are using a standard, PIC18F452-based application, these steps should not be necessary. These procedures are intended for applications being developed which will require the additional capabilities of the newer PICs.

Extend Codepage

Both the 4620 and 4520 have extended code memory. To utilise this fully, make the following alterations:

- In the source of your application, edit project.lkr
- Change

To

CODEPAGE	NAME=page	START=0×3000	END=0×FFFF	

If you are using a GLCD with your PIC18F4620 the GLCD Font of the MIOS will be overwritten by this change though, as it lies in the range of 0x7C00-0x7FFF. There are <u>two</u> approaches to prevent this (also see forum thread http://www.midibox.org/forum/index.php?topic=7540.0):

To leave out the Font space in the PIC's code memory, change

CODEPAGE	NAME=page	START=0x3000	END=0x7FFF	
----------	-----------	--------------	------------	--

To

CODEPAGE	NAME=page0	START=0x3000	END=0x7BFF	
CODEPAGE	NAME=page1	START=0x8000	END=0xFFFF	

or try this solution from TK:

- copy the mios_glcd_font.inc file from the MIOS release into your application directory, rename it to mios_glcd_font.asm
- add following code to the file header:

```
LIST P=PIC18F4620, R=DEC

DEFAULT_FONT code

FONT_ENTRY MACRO width, height, x0, char_offset

dw ((height) << 8) | (width), ((char_offset) << 8) | (x0)

ENDM
```

- change the "org" (start address) from 0x7cfc to 0xfcfc
- add a "END" at the file footer
- add the new .asm file to the MAKEFILE.SPEC (behind the MK SET OBJ statement)
- change the font pointer within the Init() routine:

```
void Init(void)
{
MIOS_GLCD_FontInit(0xfcfc);
}
```

• if you are working under MacOS or Linux, type "perl tools/mkmk.pl MAKEFILE.SPEC; make", under DOS just type "make"

The first approach has the advantage, that it isn't required to upload the font again and again with each program update. The second approach that new fonts can be inserted into the project in a similar way. Please see the forum article mentioned above on instructions how to use labels in combination with fonts.

Add Databanks

In order to give our application the ability to recognise all that lovely, lovely RAM in the newer '4620 and '4520 PICs, one or a mixture of the following options is required:

Standard Bank Size

- In the source of your application, edit project.lkr
- Change

DATABANK	NAME=miosram_u	START=0x380	END=0x5FF	PROTECTED

ACCESSBANK	NAME=accesssfr	START=0xF80	END=0xFFF	PROTECTED
То				
DATABANK DATABANK DATABANK DATABANK DATABANK DATABANK DATABANK DATABANK DATABANK DATABANK DATABANK	NAME=miosram_u NAME=gpr6 NAME=gpr7 NAME=gpr8 NAME=gpr9 NAME=gpr10 NAME=gpr11 NAME=gpr12 NAME=gpr13 NAME=gpr14 NAME=gpr15	START=0×380 START=0×600 START=0×700 START=0×800 START=0×900 START=0×000 START=0×000 START=0×000 START=0×000 START=0×000 START=0×000 START=0×000	END=0x5FF END=0x6FF END=0x7FF END=0x8FF END=0x9FF END=0xAFF END=0xBFF END=0xCFF END=0xDFF END=0xFFF END=0xFFF	PROTECTED
ACCESSBANK	NAME=accesssfr	START=0xF80	END=0×FFF	PROTECTED

Extended Bank Capacity

The above change will enable SDCC to allocate the variables in your application to any of the specified banks above. The very observant among you may have noticed that these banks are 256 bits each.... So what happens if you want to use a variable which is greater than 256 bits in size, such as a large array, or string of characters? For this, you will need to create a bank of extended size, and you will need to direct your application to use that bank to store your large variable.

In order to create memory banks of extended capacity, it is necessary to section off a greater range than those given above. A good way to go about this is to combine two or more of the default banks. The following are examples of this.

Making a single, 512-bit bank:

DATABANK NAME=miosram_u // DATABANK NAME=gpr6 // Remove this bank	START=0x380 START=0x600	END=0x5FF END=0x6FF	PROTECTED
<pre>// DATABANK NAME=gpr7 // And remove this bank</pre>	START=0×700	END=0x7FF	
DATABANK NAME=gpr67 // And create this one out	START=0x600	END=0×7FF	
DATABANK NAME=gpr8	START=0x800	END=0x8FF	
DATABANK NAME=gpr9 DATABANK NAME=gpr10	START=0x900 START=0xA00	END=0x9FF END=0xAFF	
DATABANK NAME=gpr11	START=0xB00	END=0xBFF	
DATABANK NAME=gpr12 DATABANK NAME=gpr13	START=0xC00 START=0xD00	END=0xCFF END=0xDFF	
DATABANK NAME=gpr14 DATABANK NAME=gpr15	START=0xE00 START=0xF00	END=0×EFF END=0×F7F	
PATABANK NAME-9PT 13	STAIN - ON OU	LIID-UNI /I	

ACCESSBANK NAME=accesssfr START=0xF80

END=0xFFF

PROTECTED

Note that the START of the bank is the same as the START of the first bank removed, and the END of the bank, is the same as the END of the last bank removed.

This can be extended into larger ranges, and multiple customised ranges, as below:

DATABANK NAME=miosram_u // DATABANK NAME=gpr6 // Remove this bank,			PROTECTED
<pre>// DATABANK NAME=gpr7 // And remove this bank,</pre>	START=0×700	END=0x7FF	
DATABANK NAME=gpr67			
// And create this 512-bit			
DATABANK NAME=gpr8	START=0x800	END=0x8FF	
DATABANK NAME=gpr9	START=0×900	END=0x9FF	
DATABANK NAME=gpr10	START=0×A00	END=0×AFF	
// DATABANK NAME=gpr11	START=0xB00	END=0xBFF	
// Remove this bank,			
// DATABANK NAME=gpr12	START=0xC00	END=0xCFF	
<pre>// And remove this bank,</pre>			
// DATABANK NAME=gpr13	START=0xD00	END=0xDFF	
<pre>// And remove this bank,</pre>			
// DATABANK NAME=gpr14	START=0×E00	END=0×EFF	
<pre>// And remove this bank!</pre>			
DATABANK NAME=gpr1114	START=0×B00	END=0xEFF	
// And create this 1024-bit	t (1 Kilobit) bank	out of the four 2	256-bit banks.
DATABANK NAME=gpr15	START=0xF00	END=0xF7F	
ACCESSBANK NAME=accesssfr	START=0xF80	END=0×FFF	PROTECTED

Or of course you could make the whole lot into one bank if you wanted to:

DATABANK DATABANK // That's	NAME=miosram_u NAME=gpr615 almost 2.5kilobi	START=0x600	END=0x5FF END=0xF7F	PROTECTED
ACCESSBANK	NAME=accesssfr	START=0xF80	END=0×FFF	PROTECTED

Add Sections

In order to assist in the use of these memory banks, we can give create 'sections' with names, and those names can be referenced in our code later on. I will use the 2nd example above, to demonstrate:

DATABANK NAME=miosram_u	START=0x380	END=0x5FF	PROTECTED
DATABANK NAME=gpr67	START=0×600	END=0x7FF	
// And create this 512-bit			
DATABANK NAME=gpr8 DATABANK NAME=gpr9		END=0x8FF END=0x9FF	
DATABANK NAME=gpr10		END=0xAFF	
Sirver			
DATABANK NAME=gpr1114		END=0×EFF	
<pre>// And create this 1024-bi DATABANK NAME=qpr15</pre>	t (1 Kilobit) bank ou START=0xF00	t of the four 2 END=0xF7F	256-bit banks.
DATABANK NAME-90113	STAINT-UNI UU	LIND-OXI /I	
ACCESSBANK NAME=accesssfr	START=0xF80	END=0xFFF	PROTECTED
SECTION NAME=CONFIG	POM-config		
// This SECTION entry will		file. Do NOT a	alter this
line!			
CECTION NAME	M0		
SECTION NAME=gpr8 RA // This creates a SECTION	<u> </u>	eferences the r	normal 256-hit
bank 'gpr8'	catted gpro whiteh r	crerences the r	101 mac 250-bic
	M=gpr67		
// This creates a SECTION		eferences our 5	512-bit bank
SECTION NAME=b1024 RA // This creates a SECTION	M=gpr1114	roforoncos our	1kh hank
// IIII Cleates a SECITON	carred DIOZ4 WIIICII	references our	TUD DOLLY

You may create as many or as few sections as you require for your application.

Application Code

Once these sections are created, you can use them within your application, by forcing a variable to be stored within that section. This is done using the 'udata' pragma statement with the following syntax:

```
#pragma udata section_name variable_name
```

For example, referencing the above section:

• Compile the project Fix Me! wiki link

• Upload the hex file with MIOS Studio



Still reading? Shouldn't you be writing code right now?;)

From:

http://wiki.midibox.org/ - MIDIbox

Permanent link:

http://wiki.midibox.org/doku.php?id=using_pic18f4620&rev=1158572600

Last update: **2006/10/15 09:35**

