MIDIBox AY 3 8912 - PATCH MENU

Access the PATCH MENU via F1

The Patch Menu:

LCD ROW	Func.	Data	Memo
1	NAME:	PATCHNAME	Edit the Patchname here
2	NR :	10 10 177	Select the Patch here (Patch $0 = PIC$ internal Patch / 1 to $127 = Bankstick Patches$)
3	DO :	LWF	Do L oad Patch, W rite Patch, F ormat Bankstick1
4	status	(info)	(W : OK, L : OK, F : BS PATCH 1-127)

Annotation - Editing:

LCD ROW	EDIT	KEYS		
1	NAME	Use A-Z, 0-9, SPACE = "_", after Patchname Editing the user can delete the Patchname via INST DEL key		
2	Nr.	Use crsr ← → (+ / -)		
3	Do	Use L W F		
4	status	(info)		

Annotation:

- Bankstick = Bankstick1 by default
- A "!" before the [Patchname] (@LCD ROW1) indicates, that the Patch is NOT loaded yet.
- The Fx Data will be stored (via current Patch)
- Patchname Cursor Pos. +1 = [CRSR →] or [+] or [>]
- Patchname Cursor Pos. -1 = [CRSR ←|(+SHIFT)] or [-] or [<]
- [INS DEL] or [CLR HOME] delete the patchname after patchname editing (this do not delete the patch data!).
- Format Bankstick Please note: Patch 1 to 127 will written with the current Patch Data. For instance: the User modify the MIDI Channel Tone A to 8. Now every Bankstick Patch (1 -127) will have the MIDI Channel 8 (@Tone A) after Bankstick formatting (in this way it is easy to predefine a Patch Setup for all 127 Bankstick Patches).

From:

http://wiki.midibox.org/ - MIDIbox

Permanent link:

http://wiki.midibox.org/doku.php?id=midibox ay patch menu&rev=1259674559

Last update: 2009/12/01 13:35

