


MB SEQ functions - quick reference

Detailed info for options and functions is available at

http://www.ucapps.de/midibox_seq_manual_m.html

Print-friendly (on two A4 sheets) xls version available here [mbseq_prn_.zip](#)

#	Function	Description / Options												
Dedicated button functions (these can vary depending on panel design and MBSEQ_HW.V4 file)														
1	Pattern 1,2,3,4	Select pattern/track group - G1, G2, G3, G4												
2	Track 1,2,3,4	Select track within track group - T1, T2, T3, T4. 16 tracks are available in total												
3	Trigger layer A,B,C	Select trigger layer A or B or C. Holding C opens trigger layer selection menu and allows to select others <html>	Gate	Acc	Roll	Glide	Skip	R.G(random gate)	R.V(random value)	No FX	</html>			
4	Parameter layer A,B,C	Select parameter layer A and B. C switches between C & D or with <i>Press&Hold</i> open parameter layer selection menu and to select others. Four parameter layers available by default, but CC, Pitch, Prob, Delay can be added via trigger selection menu (?) 	Note	Vel	Length	Roll	</html>							
5	Step View	View and select steps if more than 16 are used <html>	1..16	17..32	...etc</html>									
6	Pattern	Select/load pattern/track group G1, G2, G3, G4 from SD memory location												
7	Song	Select song parameters <html>	Song #	Position	Action{Stop; x1...x16; Jump Pos; Jump Song; Mixer; Tempo; Mutes}	Select patterns: G1,G2,G3,G4	</html>							
8	Edit	Enter edit mode to edit parameter layer step values and set trigger layer steps												
9	Mute	Quickly mute/unmute tracks 1...16												
10	Solo	Solo current track												
11	←/→ (Left/Right)	Move cursor position. Left has limited usage												
12	+/- (Inc/Dec)	Same as Jog Dial encoder - increases/decreases the current value												
13	Exit	Quickly exit to top (Session) menu. <html>	(return to previous menu)	Mute Tracks	Open	Save	Save as	New	Info	</html>				

#	Function	Description / Options													
14	Select	(Press&Hold) Select steps to be controlled by All function. Select brings additional options in several other menus as well													
15	All	Edit all selected steps set with Select function													
16	Copy	Copy steps from selected # to #. Step # can be edited by Select function													
17	Paste	Paste copied steps starting from # step. Step # can be edited by Select function													
18	F1 (Clear)	(Press&Hold) Wipe selected track. Other functions can be assigned in MBSEQ_HW.V4 file													
19	F2 (Select track)	(Press&Hold) Select track. Other functions can be assigned in MBSEQ_HW.V4 file													
20	F3 (Select parameter layer)	(Press&Hold) Select parameter layer A,B,C,D...etc. Other functions can be assigned in MBSEQ_HW.V4 file													
21	F4 (Select trigger layer)	(Press&Hold) Select/assign trigger layer 1..8. Other functions can be assigned in MBSEQ_HW.V4 file													
22	Rec	Open record menu <html>	Track #	Record{Live; Step}	Mode{Mono; Poly}	AStart{on; off}	Step #	TglGate	Port #	Chn #	</html>				
23	«	Rewind. Active only in song mode													
24	Stop	Stop playback and reset position to beginning													
25	Play	Start playback of patterns/song													
26	Pause	Halt/resume playback													
27	»	Forward. Active only in song mode													
28	Metronome	Toggle metronome on/off													
29	Fast	Activate Fast mode for quicker value selection with encoders. Speed options for Fast can be changed in MBSEQ_HW.V4 file													
30	Scrub	(Press&Hold) + Jog Wheel dynamically change actual position													
Menu functions															
31	Menu+Scrub	Toggle loop mode on/off													
32	Menu+Metronome	External restart used to synchronize playback starting from next step													

