

MIDIBox AY 3 8912 - Controllers

- **CONTROLLER 01 - ENVELOPE SHAPE CONTROL:**

- 00-07 dec. ==> ENVELOPE SHAPE 0
- 08-15 dec. ==> ENVELOPE SHAPE 1
- 16-23 dec. ==> ENVELOPE SHAPE 2
- 24-31 dec. ==> ENVELOPE SHAPE 3
- 32-39 dec. ==> ENVELOPE SHAPE 4
- 40-47 dec. ==> ENVELOPE SHAPE 5
- 48-55 dec. ==> ENVELOPE SHAPE 6
- 56-63 dec. ==> ENVELOPE SHAPE 7
- 64-71 dec. ==> ENVELOPE SHAPE 8
- 72-79 dec. ==> ENVELOPE SHAPE 9
- 80-87 dec. ==> ENVELOPE SHAPE 10
- 88-95 dec. ==> ENVELOPE SHAPE 11
- 96-103 dec. => ENVELOPE SHAPE 12
- 104-111 dec. => ENVELOPE SHAPE 13
- 112-119 dec. => ENVELOPE SHAPE 14
- 120-127 dec. => ENVELOPE SHAPE 15

- **ENVELOPE SHAPE CONTROL** | See =>

http://www.midibox.org/dokuwiki/midibox_ay_3_8912_envelope

-

- **CONTROLLER 02 - GLOBAL ENVELOPE FINE** (0-127 / 128-255 with +128 OFFSET CC3)

-

- **CONTROLLER 03 - GLOBAL ENVELOPE FINE +128 OFFSET** (0 = NO OFFSET, 1-128 +128 OFFSET)

-

- **CONTROLLER 04 - GLOBAL ENVELOPE COARSE** (0-127 / 128-255 with +128 OFFSET CC5)

-

- **CONTROLLER 05 - GLOBAL ENVELOPE COARSE +128 OFFSET** (0 = NO OFFSET, 1-128 +128 OFFSET)

-

- **CONTROLLER 06 - GLOBAL NOISE PERIOD** (MIDI Controller 0-127 => 0-31 NIOSE PERIOD)

-

- **CONTROLLER 07 - VOLUME A** (MIDI Controller 0-127 => 0-15 VOLUME)

-

- **CONTROLLER 08 - VOLUME B** (MIDI Controller 0-127 => 0-15 VOLUME)

-

- **CONTROLLER 09 - VOLUME C** (MIDI Controller 0-127 ⇒ 0-15 VOLUME)

-

More to come...

From:

<http://wiki.midibox.org/> - **MIDIbox**

Permanent link:

http://wiki.midibox.org/doku.php?id=midibox_ay_3_8912_cc_list&rev=1225052352



Last update: **2008/10/26 20:19**