

MIDIBox AY 3 8912 - Controllers

- **CONTROLLER 01 - ENVELOPE SHAPE CONTROL:**

- ENVELOPE SHAPE CONTROL | See ⇒

http://www.midibox.org/dokuwiki/midibox_ay_3_8912_envelope

- 00-07 dec. ==⇒ ENVELOPE SHAPE 0
- 08-15 dec. ==⇒ ENVELOPE SHAPE 1
- 16-23 dec. ==⇒ ENVELOPE SHAPE 2
- 24-31 dec. ==⇒ ENVELOPE SHAPE 3
- 32-39 dec. ==⇒ ENVELOPE SHAPE 4
- 40-47 dec. ==⇒ ENVELOPE SHAPE 5
- 48-55 dec. ==⇒ ENVELOPE SHAPE 6
- 56-63 dec. ==⇒ ENVELOPE SHAPE 7
- 64-71 dec. ==⇒ ENVELOPE SHAPE 8
- 72-79 dec. ==⇒ ENVELOPE SHAPE 9
- 80-87 dec. ==⇒ ENVELOPE SHAPE 10
- 88-95 dec. ==⇒ ENVELOPE SHAPE 11
- 96-103 dec. ==⇒ ENVELOPE SHAPE 12
- 104-111 dec. ⇒ ENVELOPE SHAPE 13
- 112-119 dec. ⇒ ENVELOPE SHAPE 14
- 120-127 dec. ⇒ ENVELOPE SHAPE 15

- **CONTROLLER 02 - GLOBAL ENVELOPE FINE** (0-127 / 128-255 with +128 OFFSET CC3)

- **CONTROLLER 03 - GLOBAL ENVELOPE FINE +128 OFFSET** (0 = NO OFFSET, 1-128 = +128 OFFSET)

- **CONTROLLER 04 - GLOBAL ENVELOPE COARSE** (0-127 / 128-255 with +128 OFFSET CC5)

- **CONTROLLER 05 - GLOBAL ENVELOPE COARSE +128 OFFSET** (0 = NO OFFSET, 1-128 = +128 OFFSET)

- **CONTROLLER 06 - GLOBAL NOISE PERIOD** (MIDI Controller 0-127 ⇒ 0-31 NIOSE PERIOD)

- **CONTROLLER 07 - VOLUME A** (MIDI Controller 0-127 ⇒ 0-15 VOLUME)

- **CONTROLLER 08 - VOLUME B** (MIDI Controller 0-127 ⇒ 0-15 VOLUME)

- **CONTROLLER 09 - VOLUME C** (MIDI Controller 0-127 ⇒ 0-15 VOLUME)

.-.

More to come...

From:

<http://wiki.midibox.org/> - **MIDIbox**

Permanent link:

http://wiki.midibox.org/doku.php?id=midibox_ay_3_8912_cc_list&rev=1225053490

Last update: **2008/10/26 20:38**

