

#	Function	Description
1	Pattern 1,2,3,4	Select pattern/track group (G1, G2, G3, G4)
2	Track 1,2,3,4	Select track within track group (T1, T2, T3, T4). 16 tracks are available in total
3	Trigger layer A,B,C	Select trigger layer A and B (C switches between C & D or if Press&Hold opens trigger layer selection)
		This is some  inline HTML

adsfasdf |

From:

<http://wiki.midibox.org/> - **MIDIbox**

Permanent link:

[http://wiki.midibox.org/doku.php?id=midibox\\_seq\\_quick\\_reference&rev=1273331640](http://wiki.midibox.org/doku.php?id=midibox_seq_quick_reference&rev=1273331640)

Last update: **2010/05/08 16:14**

