

# MB SEQ functions - quick reference

Detailed info for options and functions is available at  
[http://www.ucapps.de/midibox\\_seq\\_manual\\_m.html](http://www.ucapps.de/midibox_seq_manual_m.html)

#	Function	Description / Options
<b>Dedicated button functions (these can vary depending on panel design and MBSEQ_HW.V4 file)</b>		
1	Pattern 1,2,3,4	Select pattern/track group - G1, G2, G3, G4
2	Track 1,2,3,4	Select track within track group - T1, T2, T3, T4 (16 tracks are available in total)
3	Trigger layer A,B,C	Select trigger layer A or B or C. Holding C opens trigger layer selection menu and allows to select others   Gate   Acc   Roll   Glide   Skip   R.G(random gate)   R.V(random value)   No FX
4	Parameter layer A,B,C	Select parameter layer A and B. C switches between C & D or if <i>Pressed&amp;Hold</i> opens parameter layer selection menu and allows to select others. Four parameter layers available by default, but CC, Pitch, Prob, Delay can be added via trigger selection menu (?)   Note   Vel   Length   Roll
5	Step View	View and select steps if more than 16 are used   1..16   17..32   ...etc
6	Pattern	Select/load pattern/track group G1, G2, G3, G4 from SD memory location
7	Song	Select song parameters   Song #   Position   Action(Stop; x1..x16; Jump Pos; Jump Song; Mixer; Tempo; Mutes)    Select patterns G1,G2,G3,G4
8	Edit	Enter edit mode to edit parameter layer step values and set trigger layer steps
9	Mute	Quickly mute/unmute tracks 1...16
10	Solo	Solo current track
11	←/→ (Left/Right)	Move cursor position (Left has limited usage)
4	a b	

From:  
<http://wiki.midibox.org/> - **MIDIbox**

Permanent link:  
[http://wiki.midibox.org/doku.php?id=midibox\\_seq\\_quick\\_reference&rev=1273337422](http://wiki.midibox.org/doku.php?id=midibox_seq_quick_reference&rev=1273337422)

Last update: **2010/05/08 17:50**

