MB SEQ functions - quick reference

Detailed info for options and functions is available at
http://www.ucapps.de/midibox_seq_manual_m.html

#	Function	Description / Options
Dedicated button functions *(theese can vary depending on panel design and MBSEQ_HW.V4 file)*		
1	Pattern 1,2,3,4	Select pattern/track group - G1, G2, G3, G4
2	Track 1,2,3,4	Select track within track group - T1, T2, T3, T4. 16 tracks are available in total
3	Trigger layer A,B,C	Select trigger layer A or B or C. Holding C opens trigger layer selection menu and allows to select others `| Gate | Acc | Roll | Glide | Skip | R.G(random gate) | R.V(random value) | No FX |`
4	Parameter layer A,B,C	Select parameter layer A and B. C switches between C & D or with *Pressed&Hold* open parameter layer selection menu and allows to select others. Four parameter layers available by default, but CC, Pitch, Prob, Delay can be added via trigger selection menu *(?)* `| Note | Vel | Length | Roll |`
5	Step View	View and select steps if more than 16 are used `| 1..16 | 17..32 | ...etc`
6	Pattern	Select/load pattern/track group G1, G2, G3, G4 from SD memory location
7	Song	Select song parameters `| Song # | Position | Action{Stop; x1..x16; Jump Pos; Jump Song; Mixer; Tempo; Mutes} || Select patterns G1,G2,G3,G4 |`
8	Edit	Enter edit mode to edit parameter layer step values and set trigger layer steps
9	Mute	Quickly mute/unmute tracks 1...16
10	Solo	Solo current track
11	←/→ *(Left/Right)*	Move cursor position. *Left* has limited usage
12	+/- *(Inc/Dec)*	Same as *Jog Dial* encoder - increases/decreases the current value
13	Exit	Quickly exit to top menu
14	Select	*(Press&Hold)* Select steps to be controlled by *All* function. Obviously has usage in other situations as well

#	Function	Description / Options
15	All	Edit all selected steps set with *Select* function
16	Copy	Copy steps from selected # to #. Selection can be edited by *Select* function
17	Paste	Paste copied steps starting from # step. Selection can be edited by *Select* function
18	F1 *(Clear)*	*(Press&Hold)* Wipe selected track. Other functions can be assigned in MBSEQ_HW.V4 file
19	F2 *(Select track)*	*(Press&Hold)* Select track. Other functions can be assigned in MBSEQ_HW.V4 file
20	F3 *(Select parameter layer)*	*(Press&Hold)* Select parameter layer A,B,C,D...etc. Other functions can be assigned in MBSEQ_HW.V4 file
21	F4 *(Select trigger layer)*	*(Press&Hold)* Select/assigns trigger layer 1..8. Other functions can be assigned in MBSEQ_HW.V4 file
22	Rec	Open record menu `| Track # | Record{Live; Step} | Mode{Mono; Poly} | AStart{on; off} | Step # | TglGate || Port # | Chn # |`
23	«	Rewind. Active only in song mode
24	Stop	Stop playback and reset position to beginning
25	Play	Start playback of patterns/song
26	Pause	Halt/resume playback
27	»	Forward. Active only in song mode
28	Metronome	Toggle metronome on/off
29	Fast	Activate *Fast* mode for quicker value selection with encoders. Speed options for *Fast* can be changed in MBSEQ_HW.V4 file
30	Scrub	*(Press&Hold) + Jog Wheel* dynamically change actual position

4 a b

From:
http://wiki.midibox.org/ - **MIDIbox**

Permanent link:
http://wiki.midibox.org/doku.php?id=midibox_seq_quick_reference&rev=1273340762

Last update: **2010/05/08 18:46**