

AIN module is used to connect potentiometers to the Midibox. It's also possible to use other 0-5V analog voltage sources.

(For examples see: [Midibox Extensions](#) page)

\* [AIN Module](#) <sup>uCApps</sup>

\* [ain board parts list](#)

\* [sound.westhost.com/pots.htm](http://sound.westhost.com/pots.htm) interesting background informations about pots

From:

<https://wiki.midibox.org/> - **MIDIbox**

Permanent link:

[https://wiki.midibox.org/doku.php?id=ain\\_module&rev=1187320833](https://wiki.midibox.org/doku.php?id=ain_module&rev=1187320833)

Last update: **2007/08/27 16:09**

