

AINSER8 Board parts list



[Official Ucapps Page](#)

Parts List



: Fill the missings refs

Description	Type	Quantity	Reichelt Ref	Mouser Ref	Digikey Ref
MCP3208-CI/P	IC	1	MCP 3208-CI/P	579-MCP3208CIP	
10Ω	Resistor	1	1/4W 10	291-10-RC	
470Ω	Resistor	1	1/4W 2.2k	291-470-RC	
100nF	Cap Ceram	2	Z5U-2,5 100n	80-C412C104K5R	
10 μF 35V	Cap Elec	2	rad 10/35	667-EEA-GA1V100	
LED 3mm	LED	1	LED 3MM ST RT		
DIP16 Socket	Socket	1	GS 16	653-XR2A-1611-N	
DIL 2×5 Socket	Socket	10	PFL 10		

From:

<https://wiki.midibox.org/> - **MIDIbox**

Permanent link:

https://wiki.midibox.org/doku.php?id=ainser8_board_parts_list&rev=1465348166

Last update: **2016/06/08 01:09**

