

# DIN Board parts list



[Official Ucapps Page](#)

## Parts List

Description	Type	Quantity	Reichelt Ref	Mouser Ref	Digikey Ref
74HC165	IC	4	74HC 165	595-SN74HC165N	
ResNet 10kΩ	Res Net	4	SIL 6-5 10K	652-4606X-1LF-10K	
100nf	Capa Ceram	4	Z5U-2,5 100n	80-C412C104K5R	
Socket DIP16	Socket	4	GS 16	653-XR2A-1611-N	
Sockets DIL 2x5	Socket	2	WSL 10G		
DIL	Pinheader	1	SL 2X40G 2,54	855-M20-9982046	

## Datasheets

- [74HC165](#)

From:

<https://wiki.midibox.org/> - **MIDIbox**

Permanent link:

[https://wiki.midibox.org/doku.php?id=din\\_board\\_parts\\_list&rev=1465821119](https://wiki.midibox.org/doku.php?id=din_board_parts_list&rev=1465821119)

Last update: **2016/06/13 12:31**

