


MIDIBox AY 3 8912 - CS LED (wiring)

MIDIBox AY CS - Tone LEDs:




Tone LED Indication:

- Tone [A,B,C] On/Off
- Noise [A,B,C] ON/OFF

- Fx Option [A,B,C] ON/OFF


⋮
⋮
⋮

MIDIBox AY CS - Envelope LEDs:



Context:

- MIDIBox AY Envelope Control See ⇒ [midibox_ay_3_8912_envelope](#)



From:

<https://wiki.midibox.org/> - **MIDIbox**

Permanent link:

https://wiki.midibox.org/doku.php?id=midibox_ay_cs_led&rev=1269866585

Last update: **2010/03/29 12:43**

