


MB SEQ functions - quick reference

Detailed info for options and functions is available at
http://www.ucapps.de/midibox_seq_manual_m.html

#	Function	Description / Options													
Dedicated button functions (these can vary depending on panel design and MBSEQ_HW.V4 file)															
1	Pattern 1,2,3,4	Select pattern/track group - G1, G2, G3, G4													
2	Track 1,2,3,4	Select track within track group - T1, T2, T3, T4. 16 tracks are available in total													
3	Trigger layer A,B,C	Select trigger layer A or B or C. Holding C opens trigger layer selection menu and allows to select others <html>	Gate	Acc	Roll	Glide	Skip	R.G(random gate)	R.V(random value)	No FX	</html>				
4	Parameter layer A,B,C	Select parameter layer A and B. C switches between C & D or with <i>Press&Hold</i> open parameter layer selection menu and to select others. Four parameter layers available by default, but CC, Pitch, Prob, Delay can be added via trigger selection menu (?) 	Note	Vel	Length	Roll	</html>								
5	Step View	View and select steps if more than 16 are used <html>	1..16	17..32	...etc</html>										
6	Pattern	Select/load pattern/track group G1, G2, G3, G4 from SD memory location													
7	Song	Select song parameters <html>	Song #	Position	Action{Stop; x1..x16; Jump Pos; Jump Song; Mixer; Tempo; Mutes}	Select patterns: G1,G2,G3,G4	</html>								
8	Edit	Enter edit mode to edit parameter layer step values and set trigger layer steps													
9	Mute	Quickly mute/unmute tracks 1...16													
10	Solo	Solo current track													
11	←/→ (Left/Right)	Move cursor position. <i>Left</i> has limited usage													
12	+/- (Inc/Dec)	Same as <i>Jog Dial</i> encoder - increases/decreases the current value													
13	Exit	Quickly exit to top menu													

From:
<https://wiki.midibox.org/> - **MIDIbox**

Permanent link:
https://wiki.midibox.org/doku.php?id=midibox_seq_quick_reference&rev=1273423001

Last update: **2010/05/09 16:36**

