DIN Board parts list



Official Ucapps Page

Parts List

Description	Type	Quantity	Reichelt Ref	Mouser Ref	Digikey Ref
74HC165	IC	4	74HC 165	595-SN74HC165N	
ResNet 10kΩ	Resistor	4	SIL 6-5 10K	652-4116R-1LF-10k	
100nf	Capa Ceram	4	Z5U-2,5 100n		
Socket DIP16	Socket	4	GS 16		
Sockets DIL 2×4	Socket	2	WSL 10G		
Sockets SIL	Socket	1	SL 2X40G 2,54		

From:
https://wiki.midibox.org/ - **MIDIbox**

Permanent link:
https://wiki.midibox.org/doku.php?id=din_board_parts_list&rev=1465248499

Last update: **2016/06/06 21:28**