
C10
R37
R36
R39
R38
R17
R12
R7
R2
R32
Q1
C8
C9
R23
J8
S3 S2 S1
OUT2
OUT IN
IO8
MAIN
LED11
R10
IN3


IC5
IC2
LED4
IC10
C5
OUT3
R10
IN3
MAIN
LED11
OUT IN
OUT3


GM5x5x5
build now. schem later.™
UL 94V-0
USB


GM5x5x5
build now. schem later.™
UL 94V-0
USB
S3 S2 S1 J8
jumper table
OUT2
IN2


GM5x5x5
build now, schem later
IN1
OUT1
IN2
OUT2
IN3
OUT3
IN4
OUT4
IN5
OUT5
USB
+5V
GND
YAGEO
WIMA


YAGEO
WIMA


GM5x5x5
build now, schem later™


YAGEO

From:
https://wiki.midibox.org/ - **MIDIbox**

Permanent link:
https://wiki.midibox.org/doku.php?id=gm5x5x5_noob_guide&rev=1235474696

Last update: **2009/02/24 11:24**