KiCAD, An Open-Source Alternative to Eagle for PCB Design

1. Introduction

KiCAD is a Open Source Computer Assisted Drawing (CAD) software for designing Printed Circuit Boards (PCBs) from Schematics to Gerber Files. Its features have been enhanced through heavy development by CERN and the community. It supports up to 32 layers and has no limitation on the size of the PCB.

You can find the official website here : http://kicad-pcb.org/

2. Installation

First, download the correct installer for your operating system at

http://kicad-pcb.org/download/

Follow the instructions to get the program installed

3. Getting Started

The basic workflow in Kicad is split into 4 parts :

• First you have to create a library including all the components you will need for your design. This allow to add new components to a basic library by designing pin layout for a new used IC.

kicad

	0 Co	mpone	nt Libra	ry Editor	: /home/hyvok/Docu	ments/Electro	nics/kic	ad_libs/ard	uino_pro	_mini.i	lib		
0Ē	ΦØ	i l à] 🍕	🖶 🔁	🏴 🕘 💽 🞁	🥱 🕐 🕅	T	۹ 💥	Q (P	R	S S 8	* APM	
 ₽₽									· · · · · ·	· · · · ·			
mm							U?		1 24				Т
12						2	RXD	GND	23	<u></u>			
						. 3	RST	RST	22	-			ñ
						<u>4</u> 5	GND	Vcc	21	•			4
						· · · 6 · · ·	3	A2	19				
						• 7	4	-13- A1	18	-			
						g	5	A0 SCK	17	_			
						, 10	7	MISO	15	-			
						<u>, 11</u> 12	8	MOSI	14	-			
							9	10 APM		•			
Der			Unit	Body	Time	Description	N an	unede	Datacher				
AP	M N	one	A	Norma	al Component	Description	Ne)	words	Datasnet				
							Z 4	X 0.100	Y 0.200		dx 0.100 dy 0.200 d 0.224	Inches	Add pin

• Then you have to create a Schematic, which is the Conceptual Drawing of your electronic design. It's how components are connected together.

SHIELD1 AREF GND3	890	[aqua	rium_	light_i	tc_tim	er /] (/home	e/hyv	ok/D	ocun	nents	5/Ele	ctron	ics/A	qyari	um_	light_	timer)						
Import SHIELD1 Import Import	18] 🚵 [6 🖬		\$	¢ [[0	<u></u>	€	Q	(4	R	Ê.	Ø		240Z	š (* 1	net			ск		
Reference Name Component Library Description Key words U? DS3234 DS3234 ds3234				RST 3V3 5V 6ND1 5V 6ND1 5V 6ND1 6ND1 6ND1 6ND1 6ND1 6ND1 6ND1 6ND1	SH SSH SSH SSH SSH SV SV SV SV SV SV SV SV SV SV	IIELD:1		<u>о</u> , рі	ELD	REF	AREF AREF 13 12 11 10 10 9 9 8 7 7 6 5 5 4 4 3 2 2 1 1 0 0					MEL · · · · · · · · · · · · · · · · · · ·	· · · · · · · · · · · · · · · · · · ·	U1 Dout SCLK SCLK SCL		INT / 5	60W - 100n kHz - 234 -	5 5 3 16		total	
Reference Name Component Library Description Key words U? DS3234 DS3234 ds3234 ds3234							· ·	· · ·															 · · ·		
	Reference Name Component Library Description Key words U? DS3234 DS3234 ds3234																								

• After this you will have to make a link between components and footprints. Footprints are the layouts of pads, holes, and silkscreen drawings that are actually manufactured into the PCB, corresponding to each component.



• Lastly, the PCB Design by itself. Based upon your components list and associated footprints , you can create the PCB by placing footprints at the right place and make routing between them (which is connecting components footprints by making copper paths). You can also use the famous 3D viewer to see a simulation of the result.

📗 🔅 Applications Places System 🙋 😰 🔍		📑 💉 🌗 🖂 Thu Apr 7, 1:35 AM 📖 terry 🖒 📗
/usr/local/kicad/share/demos/test_xil_95108/carte_test.brd		S D D
File Edit View Place Preferences Design Rules Help		
🗋 🔤 🔚 🞇 🎉 🥱 🕜 🖨 🖼 🔍 🔍 👹 🗶 🎎 🛄 🅰 📕 Back <pgdn> 🛛 🔽 👹 🗱 🗱 😭</pgdn>		
Track 0.203 mm * 🔻 Via 0.889 mm * 🔻 🔀 Grid 1.270 🔻 Zoom 50 🔻		
 3D Viewer Be Preferences C O O O O O O O O O O O O O O O O O O O		Willes Upr Pront Back SoldP Back SoldP SoldP
dx 0.00 dy 0.00 View: 23.0		
Kicad (2011.03.30.BZ E ///sr/local/kicad/charo/d DD 3D Viewer	AND	
a weat (2011-05-56 Bz 🔛 /usi/iocai/kicad/share/d 😏 5D viewer		

Once your PCB Design is finished, you can export it to Gerber Files (Vectorized layers) and send it to

your favorite PCB maker.

4. Video Tutorials

Video
Video
Video



• Further Video Tutorials

5. Going Further

- KiCAD Getting started Manual
- KiCAD Librairies

6.Tips

Issues with default libraries

Symbols

While the libraries are all right for some purposes, there's an issue with many of the symbols for chips. Often these symbols have hidden power pins labeled VDD and GND, or similar. KiCAD automatically connects these together, which is bad if you want them connected to a net named something else, and even worse if there is a net with one of these names which you DON'T want connected to these pins. In addition, the naming conventions on chip pins isn't consistent, and often the chip bodies are needlessly large. Therefore, it is recommended to consider copying and editing a built-in symbol.

Footprints

Many of the footprints are just fine, though some are missing 3D models. However, some common footprints, like standard types for TO-92 transistors, are missing-you will have to create them.

From: http://wiki.midibox.org/ - **MIDIbox**

Permanent link: http://wiki.midibox.org/doku.php?id=kicad&rev=1468771683



Last update: 2016/07/17 16:08