


LoopA - Eurorack - Frontpanel with breakout PCB




I made this Breakout-PCB and Frontpanel for the midiphy LoopA [midiphy LoopA](#)


PCB Size is 172x24mm

You have to decide if you want Midi Out 3 or the Gate OUT (space thing)


The Reset Switch and the SD, Card, are still on the base PCB...

If you want use the PCB you dont have place for the stock DIN Sockets!





ON this board we have 3 micromatch Connectors, which are crimped fast on a cable
On the other side of the cable you have to solder directly to the Base-PCB,
be carefull while soldering - and follow the schematic, which is layout for 3.5 Jack Midi Type B!



Schematic

Hardware Requirements

- [midiphy LoopA caseless Kit](#)
- Soldering Iron - with a Dip that can Handle Thruhole-Parts, solder Paste...
- The other Parts from the BOM

Building and BOM

All necessary Information is printet on the PCB, but also check the Schematic...

5x "[Leiterplatten Montageblock aka Standoffs](#) 3x [Micromatch Socket 2x5Pole 1,27mm](#)

luck!

Community users working on it

- **Phatline** = PCB & Schematic, Documentation...

Just let a Private message on the forum to user already involved.

From:

<http://wiki.midibox.org/> - **MIDibox**

Permanent link:

<http://wiki.midibox.org/doku.php?id=loopa-eurorack-panel&rev=1642321076>

Last update: **2022/01/16 08:17**

