

This page will contain the information about the combined lcd/button matrix [forum topic](#) ^{uCApps}

right now I'm using a modified version of the sm_simple C example
this code will be rewritten to make it more coherent

modifications to [scan matrix example](#) ^{uCApps}

Hardware

[DOUT wiring](#)

[DIN wiring](#)

Software

in main.c:

```
...
//second shiftregister drives the leds
#define LEDOUT 1

...
void LM_SetRow(){
    MIOS_DOUT_SRSet(LEDOUT,ledtest[sm_col]);
}

///////////////////////////////
/
// This function is called by MIOS before the shift register are loaded
///////////////////////////////
/
void SR_Service_Prep(void) __wparam
{
    // call the Scan Matrix Driver
    SM_PrepCol();
    // call the Led Matrix Driver
    LM_SetRow();
}
...
```

in sm_simple.asm:

```
...
global _sm_button_column
global _sm_button_row
global _sm_button_value
global _sm_col
```

```

;; import lables
extern    _SM_NotifyToggle

; =====

accessram      udata          ; (no access ram required, these variables can
be located anywhere)

_sm_button_column  res   1      ; exported to C, therefore an "_" has been
added
_sm_button_row    res   1
_sm_button_value   res   1
_sm_col           res 1

...
SM_PrepCol
    ; select next DOUT register

    ; (current column + 1) & 0x07
    SET_BSR    sm_selected_column
    incf     sm_selected_column, W, BANKED      ; (* see note below)
    andlw    0x07
    ;_sm_col is used by LM_SetRow()
    movwf    _sm_col
    call     MIOS_HLP_GetBitANDMask    ; (inverted 1 of 8 code)
...

```

and finally in sm_simple.h:

```

...
extern unsigned char sm_button_value;
extern unsigned char sm_col;
...

```

back to [DSEQ32](#)

From:
<http://wiki.midibox.org/> - **MIDIbox**

Permanent link:
http://wiki.midibox.org/doku.php?id=dseq32_matrix&rev=1155513219

Last update: **2006/10/15 09:35**

