

This page will contain the information about the combined lcd/button matrix [forum topic](#)<sup>uCApps</sup>

right now I'm using a modified version of the sm\_simple C example  
this code will be rewritten to make it more coherent

modifications to [scan matrix example](#)<sup>uCApps</sup>

## Hardware

[DOUT wiring](#)

[DIN wiring](#)

*\*note: schematics not finished!*

## Software

in main.c:

```
...
//second shiftregister drives the leds
#define LEDOUT 1
...
void LM_SetRow(){
    MIOS_DOUT_SRSet(LEDOUT,ledtest[sm_col]);
}

///////////////////////////////
/
// This function is called by MIOS before the shift register are loaded
///////////////////////////////
/
void SR_Service_Prep(void) __wparam
{
    // call the Scan Matrix Driver
    SM_PrepCol();
    // call the Led Matrix Driver
    LM_SetRow();
}
...
```

in sm\_simple.asm:

```
...
global    _sm_button_column
global    _sm_button_row
global    _sm_button_value
```

```

global _sm_col

;; import labels
extern _SM_NotifyToggle

; =====

accessram udata ; (no access ram required, these variables can
be located anywhere)

_sm_button_column res 1 ; exported to C, therefore an "_" has been
added
_sm_button_row res 1
_sm_button_value res 1
_sm_col res 1

...

SM_PrepCol
;; select next DOUT register

;; (current column + 1) & 0x07
SET_BSR sm_selected_column
incf sm_selected_column, W, BANKED ; (* see note below)
andlw 0x07
;_sm_col is used by LM_SetRow()
movwf _sm_col
call MIOS_HLP_GetBitANDMask ; (inverted 1 of 8 code)
...

```

and finally in sm\_simple.h:

```

...
extern unsigned char sm_button_value;
extern unsigned char sm_col;
...

```

## Appendum

To avoid flickering leds when pushing a button the MIOS button debouncing should be turned off!!

Due to the setup of the SRIO driver the debounce algorithm also delays the DOUT chain when a DIN event is being debounced. So when a button is pushed the led update frequency is reduced, the higher the debounce value, the lower the update frequency.

According to this post TK will fix this in a future MIOS release:

This is something what I'm planning to solve in one of the next MIOS versions - currently the same

SR scanning routine is used for DIN and DOUT registers, which means, >when the DINs are temporary disabled due to the cheap debouncing method, the DOUT registers won't be updated.

The solution is to add a second scan routine which only services the DOUTs so long the debouncing delay is active.

## Workaround

To turn the debouncing off, set

```
#define DIN_DEBOUNCE_VALUE 0
```

back to [DSEQ32](#)

From:  
<http://wiki.midibox.org/> - **MIDIbox**



Permanent link:  
[http://wiki.midibox.org/doku.php?id=dseq32\\_matrix&rev=1156334470](http://wiki.midibox.org/doku.php?id=dseq32_matrix&rev=1156334470)

Last update: **2006/10/15 09:35**