

Changing the order of items in menu pages in mbSID v2

Overview

Have you ever thought “having the Detune menu entry next to the Finetune entry would be cool”? Then this HowTo is for you. It's one of the simplest things to change. In this example will change just that - on the “Oscillator page” we'll move “Detune” next to “Finetune”.

Difficulty level:

- easy **1** 0-2-3-4-5-6-7-8-9 hard

Required actions:

- Search/copy&paste
- Compile

Affected files [1]:

- `src/cs_menu_tables.inc`

Step-by-Step description

1. Find the right menu page table

- Open `src/cs_menu_tables.inc`.
- Find the table you want to change. Some of the available pages are:
 - `CS_MENU_TABLE_L_OSC`: Oscillator menu page for the lead engine (notice the `_L_` in the name)
 - `CS_MENU_TABLE_B_OSC`: Oscillator menu page for the bassline engine (notice the `_B_` in the name)
 - `CS_MENU_TABLE_L_FIL`: The Filter menu page for the lead engine
 - `CS_MENU_TABLE_L_LFO`: The LFO menu page for the lead engine
 - and many more. The naming conventions make it pretty easy to find the right table. If you're

not sure which one it is, you can always just read the labels (3rd column, "LFO", "Wav", "Dep" and the likes) and cross-check them with your SID.

2. Edit the table

In this example we want to edit CS_MENU_TABLE_L_OSC which looks like this:

```
; =====
; The oscillator menu
; =====
CS_MENU_TABLE_L_OSC
    db      (CS_MENU_TABLE_L_OSC_End-CS_MENU_TABLE_L_OSC)/CS_MENU_ENTRY_LEN,
0x00

    ;;          Register (00=dummy)          |<->| max    print ix
exec ix      parameter transfer
    CS_MENU_ENTRY    CS_MENU_SELECTED_OSC_FLAGS, "OSC", 0x006,
PRINT_VAR_123,    EXEC_SELPAR,    R2PP2R_VAR_OSC
    CS_MENU_ENTRY    SID_Ix_Vx_WAVEFORM,        "Wav", 0x008, PRINT_Vx_WAV,
EXEC_SELPAR,    R2PP2R_Vx_WAV
    CS_MENU_ENTRY    SID_Ix_Vx_WAVEFORM,        "S/R", 0x003, PRINT_Vx_S_R,
EXEC_TOGPAR,    R2PP2R_Vx_S_R
    CS_MENU_ENTRY    SID_Ix_Vx_DELAY,          "Del", 0x0ff, PRINT_Vx_DEC,
EXEC_SELPAR,    R2PP2R_Vx
    CS_MENU_ENTRY    SID_Ix_Vx_AD,            "Atk", 0x00f,
PRINT_Vx_DEC4U,    EXEC_SELPAR,    R2PP2R_Vx_4U
    CS_MENU_ENTRY    SID_Ix_Vx_AD,            "Dec", 0x00f,
PRINT_Vx_DEC4L,    EXEC_SELPAR,    R2PP2R_Vx_4L
    CS_MENU_ENTRY    SID_Ix_Vx_SR,            "Sus", 0x00f,
PRINT_Vx_DEC4U,    EXEC_SELPAR,    R2PP2R_Vx_4U
    CS_MENU_ENTRY    SID_Ix_Vx_SR,            "Rel", 0x00f,
PRINT_Vx_DEC4L,    EXEC_SELPAR,    R2PP2R_Vx_4L
    CS_MENU_ENTRY    SID_Ix_Vx_PITCHRANGE,    "PRn", 0x07f, PRINT_Vx_DEC,
EXEC_SELPAR,    R2PP2R_Vx
    CS_MENU_ENTRY    SID_Ix_Vx_TRANSPOSE,    "Trn", 0x07f,
PRINT_Vx_PMDEC7,    EXEC_SELPAR,    R2PP2R_Vx
    CS_MENU_ENTRY    SID_Ix_Vx_FINETUNE,    "Fin", 0x0ff,
PRINT_Vx_PMDEC8,    EXEC_SELPAR,    R2PP2R_Vx
    CS_MENU_ENTRY    SID_Ix_Vx_PORTAMENTO,    "Por", 0x0ff, PRINT_Vx_DEC,
EXEC_SELPAR,    R2PP2R_Vx
    CS_MENU_ENTRY    SID_Ix_L_OSC_PHASE,    "Phs", 0x0ff, PRINT_DEC8,
EXEC_SELPAR,    R2PP2R_PAR8
    CS_MENU_ENTRY    SID_Ix_Vx_PULSEWIDTH_L, "PW ", 0xffff,
PRINT_Vx_HEX12,    EXEC_SELPAR,    R2PP2R_Vx_12
    CS_MENU_ENTRY    SID_Ix_Vx_FLAGS1,        "PMd", 0x002, PRINT_Vx_PMD,
```

```

EXEC_TOGPAR,      R2PP2R_Vx_PMD
  CS_MENU_ENTRY   SID_Ix_Vx_FLAGS1,      "GSA", 0x001, PRINT_Vx_GSA,
EXEC_TOGPAR,      R2PP2R_Vx_GSA
  CS_MENU_ENTRY   SID_Ix_L_OSC_DETUNE,    "Det", 0x0ff, PRINT_DEC8,
EXEC_SELPAR,      R2PP2R_PAR8
#if ENABLE_SWINSID
  CS_MENU_ENTRY   SID_Ix_Vx_SWINSID_MODE, "SwM", 0x0ff,
PRINT_Vx_HEX8,   EXEC_SELPAR,      R2PP2R_Vx
  CS_MENU_ENTRY   SID_Ix_Vx_SWINSID_PHASE, "SwP", 0x0ff,
PRINT_Vx_HEX8,   EXEC_SELPAR,      R2PP2R_Vx
#endif
CS_MENU_TABLE_L_OSC_End

```

To change it all you need to do is cut the line you want to move and paste it somewhere else. For this example we will move the line

```

  CS_MENU_ENTRY   SID_Ix_L_OSC_DETUNE,    "Det", 0x0ff, PRINT_DEC8,
EXEC_SELPAR,      R2PP2R_PAR8

```

It's supposed to be after Finetune which is this line

```

  CS_MENU_ENTRY   SID_Ix_Vx_FINETUNE,    "Fin", 0x0ff,
PRINT_Vx_PMDEC8, EXEC_SELPAR,      R2PP2R_Vx

```

So after moving it up there, your table should look like this:

```

; =====
; The oscillator menu
; =====
CS_MENU_TABLE_L_OSC
  db      (CS_MENU_TABLE_L_OSC_End-CS_MENU_TABLE_L_OSC)/CS_MENU_ENTRY_LEN,
0x00

  ;;          Register (00=dummy)          |<->| max   print ix
exec ix      parameter transfer
  CS_MENU_ENTRY   CS_MENU_SELECTED_OSC_FLAGS, "OSC", 0x006,
PRINT_VAR_123,   EXEC_SELPAR,      R2PP2R_VAR_OSC
  CS_MENU_ENTRY   SID_Ix_Vx_WAVEFORM,      "Wav", 0x008, PRINT_Vx_WAV,
EXEC_SELPAR,     R2PP2R_Vx_WAV
  CS_MENU_ENTRY   SID_Ix_Vx_WAVEFORM,      "S/R", 0x003, PRINT_Vx_S_R,
EXEC_TOGPAR,     R2PP2R_Vx_S_R
  CS_MENU_ENTRY   SID_Ix_Vx_DELAY,        "Del", 0x0ff, PRINT_Vx_DEC,
EXEC_SELPAR,     R2PP2R_Vx
  CS_MENU_ENTRY   SID_Ix_Vx_AD,           "Atk", 0x00f,
PRINT_Vx_DEC4U,  EXEC_SELPAR,      R2PP2R_Vx_4U
  CS_MENU_ENTRY   SID_Ix_Vx_AD,           "Dec", 0x00f,

```

```
PRINT_Vx_DEC4L, EXEC_SELPAR, R2PP2R_Vx_4L
CS_MENU_ENTRY SID_Ix_Vx_SR, "Sus", 0x00f,
PRINT_Vx_DEC4U, EXEC_SELPAR, R2PP2R_Vx_4U
CS_MENU_ENTRY SID_Ix_Vx_SR, "Rel", 0x00f,
PRINT_Vx_DEC4L, EXEC_SELPAR, R2PP2R_Vx_4L
CS_MENU_ENTRY SID_Ix_Vx_PITCHRANGE, "PRn", 0x07f, PRINT_Vx_DEC,
EXEC_SELPAR, R2PP2R_Vx
CS_MENU_ENTRY SID_Ix_Vx_TRANSPOSE, "Trn", 0x07f,
PRINT_Vx_PMDEC7, EXEC_SELPAR, R2PP2R_Vx
CS_MENU_ENTRY SID_Ix_Vx_FINETUNE, "Fin", 0x0ff,
PRINT_Vx_PMDEC8, EXEC_SELPAR, R2PP2R_Vx
CS_MENU_ENTRY SID_Ix_L_OSC_DETUNE, "Det", 0x0ff, PRINT_DEC8,
EXEC_SELPAR, R2PP2R_PAR8
CS_MENU_ENTRY SID_Ix_Vx_PORTAMENTO, "Por", 0x0ff, PRINT_Vx_DEC,
EXEC_SELPAR, R2PP2R_Vx
CS_MENU_ENTRY SID_Ix_L_OSC_PHASE, "Phs", 0x0ff, PRINT_DEC8,
EXEC_SELPAR, R2PP2R_PAR8
CS_MENU_ENTRY SID_Ix_Vx_PULSEWIDTH_L, "PW ", 0xffff,
PRINT_Vx_HEX12, EXEC_SELPAR, R2PP2R_Vx_12
CS_MENU_ENTRY SID_Ix_Vx_FLAGS1, "PMd", 0x002, PRINT_Vx_PMD,
EXEC_TOGPARG, R2PP2R_Vx_PMD
CS_MENU_ENTRY SID_Ix_Vx_FLAGS1, "GSA", 0x001, PRINT_Vx_GSA,
EXEC_TOGPARG, R2PP2R_Vx_GSA
#if ENABLE_SWINSID
CS_MENU_ENTRY SID_Ix_Vx_SWINSID_MODE, "SwM", 0x0ff,
PRINT_Vx_HEX8, EXEC_SELPAR, R2PP2R_Vx
CS_MENU_ENTRY SID_Ix_Vx_SWINSID_PHASE, "SwP", 0x0ff,
PRINT_Vx_HEX8, EXEC_SELPAR, R2PP2R_Vx
#endif
CS_MENU_TABLE_L_OSC_End
```

3. Recompile

- * Now recompile the setup_*.asm
- * Send it to your mbSID via MIOSSstudio
- * You're all done!

From:
<http://wiki.midibox.org/> - **MIDIbox**

Permanent link:
http://wiki.midibox.org/doku.php?id=changing_the_order_of_items_in_menu_pages

Last update: **2009/02/28 22:02**



