

The aim of this page is to give the community the possibility to publish improved layouts of MBHP modules. The original layouts by TK are mostly quick solutions with focus on “first-time-right”, and therefore not very well optimized with regard to area size or number of bridges.

Even small modifications on the original layouts lead to a long process: new etch masks have to be created, the new PCB needs to be tested before it's produced in larger quantities and last but not least the documentation has to be changed: sometimes new photos are required, existing schematics and connection diagrams need to be updated in a way which avoids confusion between different layout revisions, and the support effort in the forum increases, since different layouts have to be taken into account when helping on troubleshooting.

However, all these “issues” should not prevent you from sharing your improvements with the community. They could be part of the next official layout revision. Note that the update cycle is ca. 1-2 years, so it's enough time to think about the best solutions!

When publishing your layouts here, please consider the following:

- change the version number in a meaningful way (e.g. v1 → v1\_1)
- don't remove the names of the copyright holders. But you can add your name if you want
- for best utilization, the board dimensions should be chosen in a way which matches with the “eurosize format” 160×100 mm (e.g. 80×100, 80×50, ...)
- try to let ca. 5 mm free at the borders, otherwise chances are high that tracks will be damaged during splitting the boards to smaller pieces
- consider mounting holes at the edges
- single sided boards should be preferred before double sided boards
- never use a cracked version of Eagle. Not only that this is illegal, but such version also corrupt the .brd files (they cannot be opened with the freeware version anymore)
- **IMPORTANT:** never change the part numbers, they must match with the schematic to ensure consistency

## Improved Layouts

### Edit this page to add a new one

Made by NorthernLightX - bridgeless MBHP\_AOUT and MBHP\_BURNER layout:

[http://home.quicknet.nl/qn/prive/alex.span/midibox/mbhp\\_aout\\_v1\\_bridgeless.brd](http://home.quicknet.nl/qn/prive/alex.span/midibox/mbhp_aout_v1_bridgeless.brd)

[http://home.quicknet.nl/qn/prive/alex.span/midibox/mbhp\\_burner\\_v1\\_bridgeless.brd](http://home.quicknet.nl/qn/prive/alex.span/midibox/mbhp_burner_v1_bridgeless.brd)

From:

<http://wiki.midibox.org/> - **MIDIbox**

Permanent link:

[http://wiki.midibox.org/doku.php?id=layout\\_improvements&rev=1143891614](http://wiki.midibox.org/doku.php?id=layout_improvements&rev=1143891614)

Last update: **2006/10/15 09:35**

