

A semi-conductor which has a shortage of conduction electrons, or an excess of "holes", making it more positive. A semi-conductor can be made into P-type by adding trace amounts of another element to the original semiconductor crystal. Virtually all modern transistors and diodes require sections of both P-type and N-type semi-conductors.

From:

<http://midibox.org/dokuwiki/> - **MIDIbox**

Permanent link:

<http://midibox.org/dokuwiki/doku.php?id=p-type>

Last update: **2006/10/15 09:35**

