

Thyristors are switching devices that do not require any control current once they are turned on. A small control pulse of current is all that is required to turn them on and when that pulse is removed the thyristor continues to conduct, assuming a minimum holding current is maintained by such devices as SCRs or triacs. Then there are pulse generating thyristors in which a holding current is meaningless as in the cases of unijunction transistors and Shockley diodes.

From:

<http://wiki.midibox.org/> - **MIDIbox**

Permanent link:

<http://wiki.midibox.org/doku.php?id=thyristor>

Last update: **2006/10/15 10:35**

