

WORK IN PROGRESS

REQUIRED AND WILL INCLUDE IN BULK ORDER

17x Rotary Encoder: A "standard" 16mm, 24 detent, 24 pulse encoder, however the shaft length and bushing must match. They are the same ones as used on the MB-6582.

If you already have encoders from Voti: <http://www.voti.nl/winkel/catalog.html?SW-ROT> or from a bulk order for Soundwell, then these will work.

1x Datawheel Knob:

ALBS P/N 866003, Drehknopf DK38-144 A.6/4,5 schwarz gerillt mit Fingermuld, datasheet: <http://www.albs.de/ecom/images/866003.pdf>

Note also the rotary encoder for the datawheel is "panel mounted" to the PCB, so you can adjust it's height down by maybe 5mm max. and also optionally mount it above the PCB. Also, you can adjust how much you push the knob onto the rotary encoder shaft, or shorten the shaft (it's a plastic shaft) to suit other kinds of datawheel knobs.

58x Switch: <http://www.digikey.com/scripts/DkSearch/dksus.dll?Detail?name=EG1821-ND>
<http://www.mouser.com/search/ProductDetail.aspx?qs=7Bi7Dg8SEnw0f0sbwKIXZA%3d%3d>

* switch is a "standard" 12x12mm tactile switch, but the rectangular switch cap specified below requires this exact switch.

58x Switch cap (black):

<http://www.digikey.com/scripts/DkSearch/dksus.dll?Detail?name=401-1152-ND>
<http://www.mouser.com/Search/ProductDetail.aspx?qs=qUgWstB0J2Od%252btwj9sasjw%3d%3d>

* switch cap requires the switch specified above.

16x Bicolor LEDs (red/green, 3mm round, diffused, common cathode): Mouser 859-LTL1BEKVJNN
<http://www.mouser.com/Search/ProductDetail.aspx?qs=RgVUBjWRgaCkUwHnXSBfyg%3d%3d>

8x Ceramic Cap 100nF=.1uF "104" (small axial to fit inside DIP-16 IC socket): Mouser 80-C412C104K5R

<http://www.mouser.com/Search/ProductDetail.aspx?qs=TOu4hTA4Gk%2fbW6gm%252bN6zDg%3d%3d>

12x 10k 6 Pin SIL resistor network: Mouser 264-10K-RC

<http://www.mouser.com/Search/ProductDetail.aspx?qs=%252bVbJVvxFI2tjO43guEitAw%3d%3d>

REQUIRED AND MAY NOT INCLUDE IN BULK ORDER

1x LED (red, 5mm round, diffused)

27x (28x?) LEDs (green, 3mm round, diffused)

6x 74HC165: Mouser 511-M74HC165

<http://www.mouser.com/Search/ProductDetail.aspx?qs=Mu9A%252bxKg3hTmyJWEpt0thA%3d%3d>

2x 74HC595: Mouser 511-M74HC595

<http://www.mouser.com/Search/ProductDetail.aspx?qs=lgHKUCmDFtiUPdphCdakWQ%3d%3d>

8x 16-pin DIP IC socket: Mouser 571-1-390261-4

<http://www.mouser.com/Search/ProductDetail.aspx?qs=VZ9FDhhp7Sk4VC7kjdjYg%3d%3d>

58x 1N4148 (small signal diode): Mouser 512-1N4148

<http://www.mouser.com/Search/ProductDetail.aspx?qs=i4Fj9T%2foRm8RMUj5DeFQg%3d%3d>

2x 2x5 dual row headers (for DIN/OUT connection to Core/ultracore and extension to optional button/LED matrix).

2x 2x8 dual row headers (for LCDs)

IDC connectors to connect LCD and CS boards to Core/ultracore

ribbon cable

REQUIRED AND WILL NOT INCLUDE IN BULK ORDER

2x 2 line 40 character (2x40/40x2) standard character LCD modules

MAY BE USED IN DOUG'S CASE, BUT STILL UNDECIDED

MIDI socket: <http://search.digikey.com/scripts/DkSearch/dksus.dll?Detail?name=CP-1235-ND>

Power switch:

<http://www.mouser.com/Search/ProductDetail.aspx?qs=ewGlpqF2icnsBB85JMTsOw%3d%3d>

Power socket:

<http://www.mouser.com/Search/ProductDetail.aspx?qs=4bc6C%252bcluO4fnW%2f1OprFbw%3d%3d>

From:

<https://wiki.midibox.org/> - **MIDIbox**

Permanent link:

https://wiki.midibox.org/doku.php?id=wilba_mb_seq_parts_guide&rev=1233765328

Last update: **2009/02/04 16:35**

